

ASP Keying Kit Applications

Kit No.	Car Applications	Key Blank	Locks	#1 Tumbler Refill	#2 Tumbler Refill	#3 Tumbler Refill	#4 Tumbler Refill	#5 Tumbler Refill	#6 Tumbler Refill	#7 Tumbler Refill	Spring Refill
A-00-102	British Leyland	X51 / NE19	Ignition	P-14-101	P-14-102	P-14-103	P-14-104				
	British Leyland	X29 / NE27	Ignition	P-14-111	P-14-112	P-14-113	P-14-114				
A-13-101	BMW	X59, X144 BW7, HU50	All	P-13-101	P-13-102	P-13-103	P-13-104				P-31-100
	Pontiac Lemans	X168 / HU46	All								
	Nissan, Infiniti	X237 / NSN14	All								
SERVICE NOTE: When using this kit for Nissan and Infiniti, if there is a #1 and #4 depth side by side, the throat cut of these tumblers must be filed and made in other combinations the A-13-101 kit will work with no problems. New keying kit no. A-16-108 will be available soon (listed below) specifically for the Nissan and Infiniti applications.											
A-13-102	BMW	X144 HU50	Chambers 7-11 in door locks with deadlocking	P-13-121	P-13-122	P-13-123	#4 tumbler is not used in these chambers				
A-13-103	BMW	S7BWP HU58AP	All (Left) All (Right)	P-13-131 P-13-141	P-13-132 P-13-142	P-13-133 P-13-143	P-13-134 P-13-144				P-31-100
A-13-104	BMW Motorcycle	B69K / NE5 NE31, NE62	All	P-13-151 P-13-161 P-13-171	P-13-152 P-13-162 P-13-172	P-13-153 P-13-163 P-13-173	P-13-154 P-13-164 P-13-174	P-13-155 P-13-165 P-13-175	P-13-156 (top pin, one size only)		
A-13-105	BMW 3-ser. 99-00		All	P-13-181	P-13-182	P-13-183	P-13-184				P-31-100
A-14-101 - discontinued, parts are now contained in the A-14-106 keying kit.											
A-14-103	Jaguar	X177 WAS13RAP	Ign., Door	P-14-131	P-14-132	P-14-133	see note below				P-31-100
NOTE: This lock was originally designed to have a #4 depth in the code series. A #4 depth is listed in the code series, and #4 tumblers were included in early versions of these keying kits. However in actual usage few if any vehicles were actually produced using codes including a #4 depth. As such the #4 tumbler is no longer produced and must be eliminated from the kit.											
A-14-104 - discontinued, parts are now contained in the A-14-106 keying kit.											
A-14-105	Jaguar	X86 / CEM3	Door, Trunk	P-14-151	P-14-152	P-14-153	P-14-154				P-31-100
A-14-106	Land Rover		Ign., Doors	P-14-121	P-14-122	P-14-123	P-14-124	P-14-125			P-31-100
	Range Rover Sterling	X170 / NE64	* Door, Trunk * Glove, Tank	P-14-141 P-14-161	P-14-142 P-14-162	P-14-143 P-14-163	P-14-144 P-14-164				
* Each lock has some chambers requiring the P-14-141/144 design tumblers and other chambers requiring P-14-161/164 design tumblers. These series of tumblers are 0.040 inch thickness. For 0.030 inch thickness tumblers of the same designs use kit no. A-14-107 described below.											
A-14-107	Land Rover		* Door, Trunk	P-14-171	P-14-172	P-14-173	P-14-174				P-31-100
	Range Rover	X170 / NE64	* Glove, Tank	P-14-181	P-14-182	P-14-183	P-14-184				
* These are all 0.030 inch thickness tumblers.											
A-14-108	Jaguar Tibbe locks		Except glove box	P-14-191	P-14-192	P-14-193					P-31-100
			Glove box	P-14-194	P-14-195	P-14-196					
A-14-230	British Cars, Volvo	S71B, UNI11A	All	P-14-201	P-14-202	P-14-203					P-14-200
	British Cars, Ford	F68YT / UNI8	All	P-14-211	P-14-212	P-14-213					
	British Cars	M81G, UNI19	All	P-14-221	P-14-222	P-14-223	P-14-224				
This kit also contains 1 piece of F-14-401 door lock retaining clip.											
A-16-100	Nissan, Subaru Combination Kit	X6/X7	Door, Trunk	P-16-141	P-16-142	P-16-143	P-16-144				P-16-105
		DAT6/6R	Ignition	P-16-151	P-16-152	P-16-153	P-16-154				
		X123, DAT13	All	P-16-161	P-16-162	P-16-163	P-16-164				
	Isuzu Heavy Truck	X154, DAT12R	Ign., Door								
SERVICE NOTE: This combination keying kit contains all tumblers also contained in the A-16-104, A-16-105, and A-16-106 kits. The individual kits contain some service parts not contained in this combination keying kit.											
A-16-104	Nissan, Subaru	X6/ X7 DAT6/6R	Door, Trunk some Ign.b	P-16-141	P-16-142	P-16-143	P-16-144				P-16-105
This kit also contains 1 each 5 pieces of P-16-204 face caps, 5 pieces each of P-16-201 gasket, P-16-202 return spring, P-16-203 cam retaining clip, and 1 each of P-16-301, P-16-302, P-16-303, and P-16-304 metal tailpieces.											
A-16-105	Nissan, Subaru	DAT6/6R	Ignition	P-16-151	P-16-152	P-16-153	P-16-154				P-16-105
This kit also contains 10 pieces each of P-16-620 cylinder assembly retaining pin, P-16-621 locking bar pressure spring, P-16-622 locking bar axle pin, and 1 piece each of P-16-607 locking bar and P-16-610 locking bar.											
A-16-106	Nissan, Subaru	X123/DAT13	All	P-16-161	P-16-162	P-16-163	P-16-164				P-16-105
	Isuzu Heavy Truck	X154, DAT12R	Ign., Door								

ASP Keying Kit Applications

Kit No.	Car Applications	Key Blank	Locks	#1 Tumbler Refill	#2 Tumbler Refill	#3 Tumbler Refill	#4 Tumbler Refill	#5 Tumbler Refill	#6 Tumbler Refill	#7 Tumbler Refill	Spring Refill
A-16-107	Nissan, Infiniti	NSN9P	All except glove box	P-16-171	P-16-172	P-16-173	P-16-174				P-16-105
A-16-108	Nissan, Infiniti	X237 / NSN14	All	P-16-181	P-16-182	P-16-183	P-16-184				P-16-105
A-17-111	Fiat, Alfa Romeo	F72V, W, X, Y AF4A, B, C, D	Door, Trunk	P-17-111	P-17-112	P-17-113					P-17-110
	Fiat, Alfa Romeo	F79-1, F79-3 FA1, FA3	Door, Trunk	P-17-121	P-17-122	P-17-123					P-17-120
	Fiat	X109, SIP11	Door, Trunk	P-17-131	P-17-131	P-17-133	P-17-134	P-17-135			P-17-130
This kit also contains 10 pieces each P-17-136 barrel retaining wafer, P-17-225 spring stop, and P-17-235 spring stop.											
A-18-106	Ford (TX series)	X86 / FO10	All	P-18-101	P-18-102	P-18-103	P-18-104				P-16-105
A-18-107	Ford (TC series)	X86 / FO10	All	P-18-111	P-18-112	P-18-113	P-18-114				P-16-105
A-18-108	Ford (Tibbe)	S30FDP FO21P	All	P-18-121	P-18-122	P-18-123	P-18-124				no springs
A-18-109	Ford (Tibbe) New Deluxe Kit	S30FDP FO21P	All	P-18-121	P-18-122	P-18-123	P-18-124				no springs
This kit also contains P-18-125 and P-18-126 spacers which fit between the tumblers.											
A-19-100	Honda Family Combination Kit (Honda & Acura)	X71, X128, X129, etc. HON32/33 HON37	Door, Trunk	P-19-111	P-19-112	P-19-113					P-19-100
		X71, HON32/33	Ignition	P-19-121	P-19-122	P-19-123					
		X128, HON37	Ignition	P-19-131	P-19-132	P-19-133					
		X172, HON45R	All	P-19-141	P-19-142	P-19-143	P-19-144	P-19-145	P-19-146		
SERVICE NOTE: This combination keying kit contains all tumblers also contained in the A-19-101, A-19-102, A-19-103 and A-19-104 kits. The individual kits contain extra service parts not contained in this combination keying kit.											
A-19-101	Honda, Acura	X71, X128, X129, etc. HON32/33 HON37	Door, Trunk	P-19-111	P-19-112	P-19-113					P-19-100
A-19-102	Honda, Acura	X71 HON32/33	Ignition	P-19-121	P-19-122	P-19-123					P-19-100
This kit also contains 2 each P-19-651 clip, P-19-654 large lever, P-19-655 small lever, P-19-665 small lever, P-19-656 wave washer also 5 each P-19-652 ball bearing, P-19-662 ball bearing, P-19-653 face cap, P-19-663 face cap, P-19-601 pin, P-19-602 spring, and P-19-603 ball bearing.											
A-19-103	Honda, Acura	X128, HON37	Ignition	P-19-131	P-19-132	P-19-133					P-19-100
This kit also contains 2 each P-19-684 lever, P-19-694 lever, P-19-687 cover, P-19-697 cover, P-19-688 spring, P-19-698 spring, and P-19-603 ball bearing.											
A-19-104	Honda, Acura	X172, HON45R	All	P-19-141	P-19-142	P-19-143	P-19-144	P-19-145	P-19-146		P-19-100
A-20-100	Mazda, Ford Combination Kit	X4, X5 MAZ1/1R	Door, Trunk, Some ign.	P-20-111	P-20-112	P-20-113					P-20-105
		X4, X5 MAZ1/1R	Some ign.	P-20-121	P-20-122	P-20-123					
		X26, X27, X131, MAZ2/2R, MAZ7	All	P-20-111	P-20-162	P-20-163	P-20-164				
		X188, MAZ13	All	P-33-101	P-33-102	P-33-103	P-33-104	P-33-105			
		X188, MAZ13	All with new style notched tumblers	P-20-131 (1a)	P-20-132 (2a) P-20-142 (2b)	P-20-133 (3a) P-20-143 (3b) P-20-153 (3c)	P-20-144 (4b) P-20-154 (4c)	P-20-155 (5c)			
SERVICE NOTE: This combination keying kit contains all tumblers also contained in the A-20-101, A-20-102, and A-33-101 kits. The individual kits contain some service parts not contained in this combination keying kit.											
A-20-101	Mazda, Ford	X4, X5 MAZ1/1R	Door, Boot, Some ign.	P-20-111	P-20-112	P-20-113					P-20-105
		X4, X5 MAZ1/1R	Some ign.	P-20-121	P-20-122	P-20-123					
		X26, X27, X131, MAZ2/2R, MAZ7	All	P-20-111	P-20-162	P-20-163	P-20-164				
A-20-102	Mazda, Ford, Mitsubishi, Suzuki	X188, MAZ13	All with new style notched tumblers	P-20-131 (1a)	P-20-132 (2a) P-20-142 (2b)	P-20-133 (3a) P-20-143 (3b) P-20-153 (3c)	P-20-144 (4b) P-20-154 (4c)	P-20-155 (5c)			

ASP Keying Kit Applications

Kit No.	Car Applications	Key Blank	Locks	#1 Tumbler Refill	#2 Tumbler Refill	#3 Tumbler Refill	#4 Tumbler Refill	#5 Tumbler Refill	#6 Tumbler Refill	#7 Tumbler Refill	Spring Refill
A-21-100	Mercedes-Benz 2-track and 4-track combination keying kit: Contains 10 each of all wafers also contained in the A-21-102, A-21-103, and A-21-104 kits. (Does not contain the wafers contained in the A-21-105).										
A-21-101	Mercedes-Benz	M79S, T,U, M81X, etc. HU22, YM12, HU23, YM15	All	P-21-101	P-21-102	P-21-103	P-21-104				P-31-100
		X82, X83 HU36, YM23	All	P-21-111	P-21-112	P-21-113	P-21-114				
A-21-102	Mercedes-Benz (up to 1993 only)	S50HFP, S58HFP, HU41/HU61P	All (Left) All (Right)	P-21-121 P-21-131	P-21-122 P-21-132	P-21-123 P-21-133	P-21-124 P-21-134	P-21-125 P-21-135			P-31-100
A-21-103	Mercedes-Benz	S48HFP, HU39P	All (Left) All (Right) All (Half)	P-21-141 P-21-151 P-21-161	P-21-142 P-21-152 P-21-162	P-21-143 P-21-153 P-21-163	P-21-144 P-21-154 P-21-164	P-21-145 P-21-155 P-21-165			P-31-100
A-21-104	Mercedes-Benz 94+ C-Class, E-Class	S58HFP, HU61P	All (Left) All (Right)	P-21-171 P-21-181	P-21-172 P-21-182	P-21-173 P-21-183	P-21-174 P-21-184	P-21-175 P-21-185			P-31-100
A-21-105	Mercedes-Benz 96+ S-Class	S48HFP, HU39P	Ignition only								P-31-100
A-24-101	Chevy, Geo, Isuzu Isuzu Heavy Truck	X143, GM11 X158 / ISU2	All	P-24-101	P-24-102	P-24-103	P-24-104				P-24-105
A-25-101	Peugeot, Renault	X116, X147, NE55, NE72	All	P-25-266 (M top pin)	P-25-267 (N top pin)	P-25-268 (P top pin)	P-25-269 (R top pin)	P-25-280 (S top pin)			P-25-400
				P-25-256 (M bottom pin)	P-25-257 (N bottom pin)	P-25-258 (P bottom pin)	P-25-259 (R bottom pin)	P-25-281 (S bottom pin)			
A-25-273	Renault	X85, NE42, NE49	Door, Luggage	P-25-140 ("B" wafer)	P-25-151 ("D" wafer)	P-25-142 ("E" wafer)	P-25-143 ("G" wafer)				P-25-300
A-26-101	Porsche 911, 914	A81L, A81M PW1, PW2	All	P-26-101	P-26-102	P-26-103	P-26-104				P-31-100
	Porsche 928	HF52P, HU42P	All	P-26-111	P-26-112	P-26-113	P-26-114				
A-28-101	Saab	X52, YM22	All	P-28-100	P-28-101	P-28-102	P-28-103				P-31-100
NOTE To correspond with the original markings, Saab tumblers are numbered "0, 1, 2, 3" with "0" being the shallow cut.											
A-28-102	Saab	S32YSP, YM30P	All	P-28-110	P-28-111	P-28-112	P-28-113	P-28-114	P-28-115	P-28-116	P-31-100
				P-28-117 deepest cut							
NOTE To correspond with the original markings, Saab tumblers are numbered "0, 1, 2, 3, 4, 5, 6, 7" with "0" being the shallow cut.											
A-30-104	Toyota Toyota KIA Honda Cycle Hyundai, Suzuki Hyundai Hyundai Isuzu, Mitsubishi Mitsubishi Mazda	T80R, TOY4 X37, TOY11 KIA1RP X84, HON31/R X54, TOY4R X161, HYN1 X160, HYN2R X54, TOY4R X151, MIT2R, X60, MAZ8	All	P-30-141	P-30-142	P-30-143	P-30-144				P-30-105
A-30-105	Toyota	X151, TOY30	All	P-30-151	P-30-152	P-30-153	P-30-154	P-30-155	P-30-156	P-30-157	P-24-105
A-30-106	Toyota Mitsubishi Hyundai Hyundai Suzuki, GEO	X174, TOY38R X176, MIT8 X216, HYN6 X232, HYN7R X185, SZ12	All	P-30-161	P-30-162	P-30-163	P-30-164				P-24-105
A-30-107	Toyota	T81B, TOY18	All	P-30-171	P-30-172	P-30-173	P-30-174				P-30-105
A-30-108	Toyota	X217, TOY43	All full wafer All half wafer	P-30-181 P-30-185	P-30-182 P-30-186	P-30-183 P-30-187	P-30-184 P-30-188				P-30-108
A-30-109	Toyota	X223, TOY46R	All full wafer All half wafer	P-30-191 P-30-195	P-30-192 P-30-196	P-30-193 P-30-197	P-30-194 P-30-198				P-30-108
A-30-110	Lexus Mazda Millenia	LXP90P TOY40P	All Full Tumblers	P-30-110	P-30-111	P-30-112	P-30-113 P-30-114 *	P-30-115			P-30-108
			All half tumblers	not used	P-30-116	P-30-117	P-30-118	P-30-119			
* P-30-114 is a special no. 4 wafer notched on the top. P-30-113 is also a no. 4 wafer with no notch on top.											
A-30-111	Lexus (Toyota)	TOY48	All	P-30-121	P-30-122	P-30-123					P-30-108

ASP Keying Kit Applications

Kit No.	Car Applications	Key Blank	Locks	#1 Tumbler Refill	#2 Tumbler Refill	#3 Tumbler Refill	#4 Tumbler Refill	#5 Tumbler Refill	#6 Tumbler Refill	#7 Tumbler Refill	Spring Refill	
A-30-150	Toyota Family Lock Combination Kit also Daihatsu, Holden, Mitsubishi, Hyundai, Isuzu, Honda Cycles, Mazda, Suzuki	T80R, TOY4 X37, TOY11 KIA1RP X84, HON31/R X54, TOY4R X161, HYN1 X160, HYN2R X54, TOY4R X151, MIT2R, X60, MAZ8	All	P-30-141	P-30-142	P-30-143	P-30-144				P-30-105	
		X151, TOY30	All	P-30-151	P-30-152	P-30-153	P-30-154	P-30-155	P-30-156	P-30-157	P-24-105	
		X174, TOY38R X176, MIT8 X216, HYN6 X232, HYN7R X185, SZ12	All	P-30-161	P-30-162	P-30-163	P-30-164					P-24-105
		T81B, TOY18	All	P-30-171	P-30-172	P-30-173	P-30-174					P-30-105
		X217, TOY43	All full wafer All half wafer	P-30-181 P-30-185	P-30-182 P-30-186	P-30-183 P-30-187	P-30-184 P-30-188					P-30-108
		X143, GM11 X158 / ISU2	All	P-24-101	P-24-102	P-24-103	P-24-104					P-24-105
SERVICE NOTE: This combination keying kit contains all tumblers also contained in the A-30-104, A-30-105, A-30-106, A-30-107, A-30-108, and A-24-101 kits. Individual kits contain some extra service parts not contained in this combination keying kit.												
A-31-100	Original Volkswagen Combination Keying Kit, contains all tumblers also contained in the A-31-301, A-31-302, A-31-303, A-31-304, and A-31-305 kits. This kit discontinued when sold out, replaced by A-31-150 described below.											
A-31-150	New Volkswagen Combination Keying Kit, contains all tumblers also contained in the A-31-301, A-31-303, A-31-304, A-31-305, A-31-306, and A-31-307 kits. This kit replaces A-31-100.											
A-31-301	Volkswagen, Audi, Porsche	X9, X88, X110, X139, VO9, WT7, WT9, VO13	Most ignition locks	P-31-101	P-31-102	P-31-103	P-31-104					P-31-100
			Door & Trunk	P-31-111	P-31-112	P-31-113	P-31-114					
A-31-302	Volkswagen	V78G, V78J, V81V, V81W VO4R, VO10, VO11	Ignition	P-31-201	P-31-202	P-31-203	P-31-204					P-31-100
			Some door locks	P-31-211	P-31-212	P-31-213	P-31-214					
SERVICE NOTE: This kit is discontinued when sold out. The P-31-201, 202, 203, 204 series tumblers will be available in new kit no. A-31-307. Refills from the 212, 213, and 214 series will continue to be available until sold out.												
A-31-303	Volkswagen, Mercedes, others	V68D, V68L, HU54, HU3, others	All	P-31-301		P-31-303		P-31-305				P-31-100
A-31-304	Volkswagen	V78G, V78J, V81V, V81W VO4R, VO10, VO11	Some door locks	P-31-221	P-31-222	P-31-223	P-31-224					P-31-100
			Door locks	P-31-231	P-31-232	P-31-233						
A-31-305	Volkswagen, Audi	X139, WT9	Some ign.	P-31-151	P-31-152	P-31-153	P-31-154					P-31-100
A-31-306	Volkswagen, Audi	HU66AT2	All	P-31-161	P-31-162	P-31-163	P-31-164					P-31-100
A-31-307	Volkswagen	V78G, V78J, V81V, V81W VO4R, VO10, VO11	Ignition	P-31-201	P-31-202	P-31-203	P-31-204					P-31-100
A-32-101	Volvo	X80, X140, NE40, NE51 X30, NE26	Ign. & Door	P-32-101	P-32-102	P-32-103	P-32-104					P-31-100
			Door & Trunk	P-32-111	P-32-112	P-32-113	P-32-114					
A-32-102	Volvo Die Cast tumblers	NE66P	All	P-32-121	P-32-122	P-32-123	P-32-124	P-32-125				P-32-120
	Volvo Stamped brass tumblers	NE66P	All	P-32-131 (R1) P-32-141 (L1)	P-32-132 (R2) P-32-142 (L2)	P-32-133 (R3) P-32-143 (L3)	P-32-134 (R4) P-32-144 (L4)	P-32-135(31R) P-32-145(31L)				P-32-140
A-32-103	Volvo new design wafers	NE66P	All	P-32-151 P-32-161	P-32-152 P-32-162	P-32-153 P-32-163	P-32-154 P-32-164					P-31-100
A-32-104	Volvo 40 series and some Volvo trucks	S59HFP, S60HFP	All	P-32-171	P-32-172	P-32-173	P-32-174					P-31-100
A-33-101	Isuzu / Honda Suzuki Mazda	X198/GM24R X186/SZ11R X188/MAZ13	All	P-33-101	P-33-102	P-33-103	P-33-104	P-33-105				P-24-105
A-36-101	Hyundai, Kia	X196/HYN5R	All	P-36-101	P-36-102	P-36-103	P-36-104					P-24-105

ASP Keying Kit Applications

Kit No.	Car Applications	Key Blank	Locks	#1 Tumbler Refill	#2 Tumbler Refill	#3 Tumbler Refill	#4 Tumbler Refill	#5 Tumbler Refill	#6 Tumbler Refill	#7 Tumbler Refill	Spring Refill
A-40-101	Ford Aspire	X231 / FO34	Ignition	P-40-101	P-40-102	P-40-103	P-40-104				P-24-105
			Door & Trunk	P-40-111	P-40-112	P-40-113	P-40-114				
A-41-103	Buick Park Avenue Cadillac Seville	B97	Door & Trunk	P-41-111	P-41-112	P-41-113	P-41-114				P-00-101
A-41-104	Buick Le Sabre Pontiac Bonneville	B97	All	P-41-121	P-41-122	P-41-123	P-41-124				P-00-101
A-41-105	Buick Park Avenue Saturn 2000	B97, B96	Ignition	P-41-131	P-41-132	P-41-133	P-41-134				
A-41-106	Cadillac Seville	B97	Ignition	P-41-141	P-41-142	P-41-143	P-41-144				
A-41-150	New General Motors and Saturn Combination Keying Kit: Contains all tumblers also contained in the A-41-103, A-41-104, A-41-105, A-41-106, and A-49										
A-42-100	Ford 10-cut Combination Kit	See A-42-104 See A-42-106	Door & Trunk	P-42-141	P-42-142	P-42-143	P-42-144	P-42-145			P-42-140
			Door & Trunk	P-42-161	P-42-162	P-42-163	P-42-164	P-42-165			
A-42-104	Ford 10-cut	1184FD,H54, FO35, etc.	Door	P-42-141	P-42-142	P-42-143	P-42-144	P-42-145			P-42-100
This kit also contains 5 each of face caps P-42-201, P-42-202, P-42-203, P-42-204, and P-42-205.											
A-42-106	Ford Escort, Villager Nissan Quest	1184FD,H54, FO35, etc.	All except ignition	P-42-161	P-42-162	P-42-163	P-42-164	P-42-165			P-42-100
A-42-107	Ford 10-cut	1184FD,H54, FO35, etc.	Glove, Stowage	P-42-171	P-42-172	P-42-173	P-42-174	P-42-175			P-42-100
A-42-108	Ford 1952-up (single sided keys)	1127FD, FO4 H27 & similar	All	P-42-181	P-42-182	P-42-183	P-42-184	P-42-185			P-42-180
A-42-110	Ford 5-cut double sided (pins)	1167FD, S1167FD, H50, H51, FO6, FO14R	All	P-42-131	P-42-132	P-42-133	P-42-134	P-42-135			P-42-130
This kit also contains 1 package each P-42-285 and P-42-286 spring cover retainers.											
A-42-111	Ford 10-cut sidebar ignition	1184FD, H54 FO35, etc.	Ignition	P-42-191	P-42-192	P-42-193	P-42-194	P-42-195			P-42-190
This kit also contains spring cover retainers P-42-288.											
A-42-112	Ford 5-cut double sided (wafers)	S1167FD, H50, FO14R	Glove Box, Stowage	P-42-121	P-42-122	P-42-123	P-42-124	P-42-125			P-42-120
A-42-113	Ford Focus 2000	1196FD, H75	Door, Luggage	P-42-151	P-42-152	P-42-153	P-42-154	P-42-155			P-42-120
A-42-150	Ford Combination kit	see A-42-109	Glove, Stow	P-42-121	P-42-122	P-42-123	P-42-124	P-42-125			P-42-140
		see A-42-103	Pin tumblers	P-42-131	P-42-132	P-42-133	P-42-134	P-42-135			P-42-130
		see A-42-104	Wafers	P-42-141	P-42-142	P-42-143	P-42-144	P-42-145			P-42-140
		see A-42-106	Wafers	P-42-161	P-42-162	P-42-163	P-42-164	P-42-165			P-42-140
		see A-42-107	Wafers	P-42-171	P-42-172	P-42-173	P-42-174	P-42-175			P-42-140
see A-42-111	Ign. wafers	P-42-191	P-42-192	P-42-193	P-42-194	P-42-195				P-42-190	
This kit also contains spring cover retainers P-42-285, P-42-286, and P-42-288											
A-49-101	Saturn 1997		All	P-49-101	P-49-102	P-49-103	P-49-104				