

EAGLE DOOR LOCKS

General information as follows:

1. Key blank references are for the profile only, using one of the more well-known blank numbers. This list does not include all variations of different head shapes, lengths, or transponders, the main object is to identify which key profile enters the lock.
2. Unless specified otherwise pawls are not included with replacement locks, the original pawls must be reused.
3. Items marked DWO are discontinued when out. The part numbers are listed for the benefit of those who already have stock.
4. Remember – Driver side is LEFT, Passenger side is RIGHT

Special note: For heavy trucks named Eagle see International Trucks

Model	Years	Key	Part description	Part no.	Part description	Part no.	Notes
All - 4WD wagon & sedan	1981-88	RA4	Lock service package	D-43-203	Coded pair	DP-43-103	Use tumbler series P-43-101/115
			NOTE: D-43-203 may come as a coded lock with extra face cap included, or as an unassembled service pack.				
2000GTX (Canada)	1988-93	MIT1	See Mitsubishi Galant 1988-93				
Medallion sedan	All	RN29	Uncoded service pack	D-27-109	Use face cap P-27-201 Use tumbler series P-25-150/180 series		
			Coded pair complete locks with pawls	DP-27-107	NOTE: DP-27-107 cannot be rekeyed to match the original car key.		
Medallion station wagon	All	RN31	Uncoded service pack with pawl RH & LH	D-27-207	Use tumbler series P-25-250/281 series		
			Coded pair complete locks with pawls	DP-27-107	Use tumbler series P-25-250/281 series		
Premier	1988-91	RN29	Uncoded service pack	D-27-109	Use face cap P-27-201 Use tumbler series P-25-150/180 series		
			Coded pair complete locks with pawls	DP-27-107	NOTE: DP-27-107 uses RN31 key and cannot be rekeyed to match the original RN29 car key.		
Summit	1989-92	MIT1	Coded lock without pawl	D-22-114	If original pawl cannot be reused use pawls P-22-303 (RH) or P-22-304 (LH) Use face cap P-30-217 chrome or P-30-218 black Use tumbler series P-30-161/164		
Summit	1993-96	MIT3	Complete lock with pawl reversible R&L	D-22-113	Use tumbler series P-20-131/155		
Summit Wagon (Colt Vista)	1984-91	DC3	Lock service package no pawl	D-22-207	Previously available as D-22-107 or D-22-105 complete locks If original pawl cannot be reused use pawls P-22-301 (RH) or P-22-302 (LH) Use face cap P-22-201 chrome, or P-22-202 black Use tumbler series P-30-141/144		
Summit Wagon (Colt Vista)	1992-94	MIT1	Complete lock with pawls RH & LH (type without switch)	D-22-140	Previously available as D-22-120 right side and D-22-121 left side Use tumbler series P-30-161/164		
			Complete lock RH (type with switch, must reuse the original switch)	D-22-132	Complete lock LH (type with switch, must reuse the original switch)	D-22-133	Use tumbler series P-30-161/164
Talon	1990-94	MIT1	Complete lock RH	D-22-111	Complete lock LH	D-22-112 (DWO)	Use tumbler series P-30-161/164
Talon	1995-99	MIT1	Coded lock without pawl	D-22-230	Previously available as complete locks D-22-130 (RH) and D-22-131 (LH) If original pawl cannot be reused, use P-22-306 (RH) or P-22-307 (LH) Use tumbler series P-30-161/164		
Vision (LH)	1993-94	Y155 Y160	Uncoded service pack chrome	DL4817U	Coded pair chrome	DL4817	Use face cap RP6215 (P-44-203) Use tumbler series P-44-101/104
			Uncoded service pack black	DL4823U	Coded pair black	DL4823	Use face cap RP6220 (P-44-204) Use tumbler series P-44-101/104
Vision (LH)	1995-98	Y160	Uncoded service pack chrome	DL6847U	Coded pair chrome	DL6847	Use face cap RP6215 (P-44-203) Use tumbler series P-44-111/114
			Uncoded service pack black	DL6846U	Coded pair black	DL6846	Use face cap RP6220 (P-44-204) Use tumbler series P-44-111/114
Vista			See Summit Wagon				
Vision (LH)	1995-98	Y160	Uncoded service pack chrome	DL6847U	Coded pair chrome	DL6847	Use face cap RP6215 (P-44-203) Use tumbler series P-44-111/114
			Uncoded service pack black	DL6846U	Coded pair black	DL6846	Use face cap RP6220 (P-44-204) Use tumbler series P-44-111/114

Scroll down for tumbler and keying kit information

EAGLE DOOR LOCKS

Which tumblers and keying kits to use:

The chart below lists which tumblers and keying kits to use according to which key blank the lock uses.

Chrysler is different from most other car manufacturers because locks using the same keyway may use different tumblers depending upon the code series and when it was manufactured. As such these tumbler references are correct only to the extent of information that is available to us.

The tumbler series used for each specific year and model application is listed in the notes section of the main lock application chart.

Key Blank	Tumbler #1 depth	Tumbler #2 depth	Tumbler #3 depth	Tumbler #4 depth	Tumbler #5 depth	Tumbler #6 depth	Keying kits and Notes
DC1, DC3	P-30-141	P-30-142	P-30-143	P-30-144			A-30-116 current keying kit Also contained in the A-30-104 and A-30-150 keying kits which are no longer available for purchase.
MIT1	P-30-161	P-30-162	P-30-163	P-30-164			A-30-106 current keying kit Also contained in the A-30-150 keying kit which is no longer available for purchase.
MIT3	P-20-131	P-20-132	P-20-133	P-20-144	P-20-155		A-20-103 current keying kit containing only this series A-20-150 current keying kit containing this and the MZ13 series Also contained in keying kit A-20-100 and A-20-102 no longer available for purchase (DWO)
RA4 wafer	P-43-101	P-43-112	P-43-113	P-43-114	P-43-115		A-43-101 keying kit
RN29	P-25-156 (M depth)	P-25-157 (N depth)	P-25-158 (P depth)	P-25-159 (R depth)	P-25-180 (depth)		A-25-102 keying kit
RN31 Pin tumblers	P-25-256 M bottom pin P-25-266 M top pin	P-25-257 N bottom pin P-25-267 N top pin	P-25-258 P bottom pin P-25-268 P top pin	P-25-259 R bottom pin P-25-269 R top pin	P-25-280 S bottom pin P-25-281 S top pin		A-25-101 keying kit
Y154 Y155 Y157 Y160	P-44-101 RP6201 321761	P-44-102 RP6202 321762	P-44-103 RP6203 321763	P-44-104 RP6204 321764			Narrow tumblers – 0.2 inch width A-44-104 current keying kit Also contained in SK6949 and SK7072 keying kits (DWO)
Y160 Except sidebar ignition locks	P-44-111 RP7590 322361	P-44-112 RP7591 322362	P-44-113 RP7592 322363	P-44-114 RP7593 322364			Wide tumblers – 0.275 inch width A-44-104 current keying kit Also contained in SK6949 and SK7072 keying kits (DWO)

Tumbler springs:

For locks using double bitted keys narrow tumblers P-44-101/104 - part no. RP6419

For locks using double bitted keys wide tumblers P-44-111/114 - part no. RP7595

For locks using RA4 keys - part no. RP6429

For locks using RN29 key - part no. P-25-300

For locks using RN31 key (pin tumbler) - part no. P-25-400

Scroll down for more

EAGLE DOOR LOCKS

For locks using DC1, MIT1, MIT3, MIT6, and other similar keys (Japanese design locks),
P-00-100 - currently active part number - 100 springs per pack

Part numbers previously used, now superseded to P-00-100

P-16-105	P-30-108
P-19-100	RP6546
P-20-105	RP6612
P-20-115	RP6731
P-24-105	RP6822
P-30-105	