

GMC TRUCKS UP TO 1966

General information as follows:

1. Key blank references are for the profile only, using one of the more well-known blank numbers. This list does not include all variations of different head shapes, lengths, or transponders, the main object is to identify which key profile enters the lock.
2. Identify which tumblers and keying kits to use according to the separate chart organized by the key blank numbers.

IGNITION LOCKS

All	1946-66	B10	Coded cylinder	LC1420	
-----	---------	-----	----------------	--------	--

Illustrations:

LC1420



DOOR LOCKS

Door locks using B10 / B11 keys are not currently available from ASP

Tumblers and keying kits:

Key Blank	Tumbler #1 depth	Tumbler #2 depth	Tumbler #3 depth	Tumbler #4 depth	Tumbler #5 depth	Keying kits and Notes
B10, B11	P-41-101 RP6038 322051	P-41-102 RP6039 322052	P-41-103 RP6040 322053	P-41-104 RP6041 322054	P-41-105 RP6042 322055	Tumbler springs: RP6037 (P-41-100) SK6035 keying kit supplied by ASP