STERLING LOCKS (SEDAN 1987-91)

This section is for Sterling cars 1987-91 only. For Sterling trucks:

360 - same as Mitsubishi Fuso

Bullet – same as Ram pickup (Dodge Ram)

Cargo - same as Ford Cargo

Others with Ford locks (Acterra, A-Line, L-Line) - see Ford Truck

Ignition Locks

Model	Years	Part description	Part no.	Notes
All	1987-90	Complete lock and switch	C-14-221	Use tumbler series P-14-121/125
All	1991	Complete lock and switch	C-14-226	Use tumbler series P-14-121/125

Door Locks

Model	Years	Part description	Part no.	Part description	Part no.	Notes
All	1987-91	Complete lock RH	D-14-221	Complete lock LH	D-14-222	Use tumbler series P-14-121/125

Rear Compartment Locks

Modet	Years	Part description	Part no.	Notes
All	1987-90	Complete lock 1987-90 (VIN up to 276670)	B-14-221	Use tumbler series P-14-121/125
All	1990	Complete lock VIN 276671 up	B-14-222	Use tumbler series P-14-121/125
All	1991	Complete lock	B-14-223	Use tumbler series P-14-121/125

Glove Compartment Locks

Model	Years	Part description	Part no.	Notes
All	1987-91	Uncoded lock	G-14-221	

Which tumblers and keying kits to use:

The chart below lists which tumblers and keying kits to use according to which key blank the lock uses. Some of these parts are no longer available for new purchase but are listed for the benefit of those who already have them (marked DWO / Discontinued When Out)

Key Blank	#1 depth tumbler	#2 depth tumbler	#3 depth tumbler	#4 depth tumbler	Other	Springs	Keying kits and Notes
X170	P-14-121	P-14-122	P-14-123 (DWO)	P-14-124	P-14-125 (alternate #2 depth)	P-31-100	Contained in the following keying kits which are no longer available for purchase: A-14-101, A-14-106 and A-14-113. Refill packs will continue to be available until sold out